



Display Panel, Key Reset and Tone Mute – **EDP-001/WH**



This display is a large illuminated, LCD readout, with a membrane switch and key reset facility. It can be surface mounted on a back box which is supplied. When a call is activated on the system the display will tone and give an indication to the location of the calls origin. Tone can be muted (in the vicinity of the nurse base) if required by pressing the tone mute switch. Calls can be centrally reset by the use of a key. If more than one call is activated in one instance then the display will rotate between calls, two locations will be displayed at a time. The key reset will cancel calls on a fifo basis (first in first out). This unit is available in white plastic.

Part numbers for these units are;
Plastic – EDP-001/WH